



### INSTRUCTION FOR USE:

- Clean and dry the floor.
- Remove the protective film of the floor-side and place the mat careful not to create wrinkles and creases.
- Remove the protective film in the upper layer.
- The mat is ready for use.
- When the layer lose his adhesiveness, remove the sheet through the numbered label.

### PACKAGING AND CHARACTERISTICS:

- Carton box including 4 or 8 mats.
- Do not bend the pack, keep these items in a dry place, preferably not exposed to light and protected from dust

Good high temperature strength, good UV and ageing resistance.

- Temperature: Optimum: min. 15° max. 30°
- Of use: min. -20° max. 70°
- Borderline: min. - 25° max. 90°
- Electrostatic charge: on the floor with a new mat: form -80 to -120 V/inch

### WARNINGS:

- Flammability: low. The product can catch fire only if in contact with open flames. If inflamed, could cause tearing and suffocation.
- Contact with the skin: only in case of hypersensitivity. Rinse with cold water and consult your doctor.
- Eye contact, injection and inhalation: not applicable.

### DURATION:

- The layer duration depends on the daily passages on it.
- 2 years if correctly conserved.
- Pack: neutral carton box or cardboard sheets closed with staples.